

RYO Aperture

- ① Cutoff/Gain lvl indicator.
- ② Cutoff Frequency/VCA Initial Knob.
- ③ Three position mode switch [when res off]:
 - LPF: Non resonant lowpass filter.
 - Both: Non resonant lowpass gate.
 - VCA: Standard Expo VCA.
- ④ CV attenuator for Cutoff Freq/VCA CV
- ⑤ Resonance Manual Lvl Knob.
- ⑥ Resonance on/off switch [when res on, mode switch gives]:
 - LPF: Resonant lowpass filter.
 - Both: Resonant lowpass gate.
 - VCA: 6dB variety of resonant lowpass gate.
- ⑦ Input Signal Lvl - will overdrive in range marked.
- ⑧ Klang Input (feed it a trig or other control voltage!).
- ⑨ Cutoff Freq/VCA CV input.
- ⑩ Signal Input.
- ⑪ Signal Output.

Width: 8 hp

